

Options for Belt Weighing Feeders

Feeder Accessories

(1) Charge Hopper

Select from the following 3 type. (Available in capacity rating, too.)

50 L : Mounts directly on the Belt Weighing Feeder.

100 L/200 L : Supported so that its weight is not applied to the inlet of the Belt Weighing Feeder.

(2) Level Detectors (Installed on the charge hopper)

It can be selected by high lever detectors which type of paddle, vibratory or electrostatic.

(3) It can be selected by low lever detectors which type of paddle, vibratory or electrostatic.

(4) Inlet Slide Gate

Installed on the lower end of the charge hopper. Closing the inlet slide gate enable you to adjust the Belt Weighing Feeder while the bulk material is still in the charge hopper.

(5) Vibrators

Breaking arching (Bridging) device for difficult handle materials.

(6) Inlet Flexible Joint

Flexibly connects the upper units and the Belt Weighing Feeder's inlet.

(7) Sample Valve

Available in a variety of configurations. 304 stainless steel sanitary construction.

